


**Notes:**

1. VE: Flash for VME bus access error OR On for Geog-Addr error (i.e. wrong slot).
2. VA: Flashes when TIM is accessed (addressed) by VME correctly.
3. RB: Shows status of ROD-Busy (note: In Stand-Alone Mode TIM is normally busy)
4. TB: Shows status of TIM-BusyOut

All LEDs (apart from power supplies) have a 60ms pulse stretcher for better visibility.



TIM3 Front-Panel

